

# KAMAMI

## KAmodRPiRTC



Rev. 20200923114814


Źródło: <https://wiki.kamamilabs.com/index.php/KAmodRPiRTC>

**Spis treści**

Description .....	1
Basic features and parameters .....	2
Standard equipment .....	3
Schematic .....	4
View of board .....	5
Embedded RTC .....	6
Installation of expander on RaspberryPi minicomputer .....	7
Installation of expander on RaspberryPi+ minicomputer .....	8

## Description

KAmodRPiRTC is a functional expander for RaspberryPi and Raspberry Pi+ minicomputers, that make possible to equip them with RTC real time clock (M41T00S from STMicroelectronics offer) integrated with the calendar and automatic battery maintaining.



## Basic features and parameters

- compatibility with minicomputer RaspberryPi and RaspberryPi+
- Communication with microporcessor systems via I2C interface (channel 0)
- Embedded one-chip RTC from STMicroelectronics (M41T00S)
- Extended I/O connector of RPi minicomputer
- Embedded battery to maintaining of RTC work
- Power supply voltage range 2.7...5.5VDC
- Power consumption <400 µA




The expander is adapted to cooperate also with RaspberryPi+ minicomputers


## Standard equipment

Code	Description
<b>KAmodRPiRTCr</b>	• Assembled and launched board with battery 3V (CR2032)

## Schematic




## View of board



## Embedded RTC


In the expander are used a single-chip RTC M41T00S from STMicroelectronics. The system is a complete calendar, it is also equipped with a monitor of the supply voltage level and an automatic switch connecting the battery supply voltage in the event of a failure of the main supply voltage. The M41T00S chip communicates with the microprocessor of the RPi minicomputer (RPi+) using the I<sup>2</sup>C interface (channel 0).




The lines used for RTC communication with the microprocessor are shown in the table below.

Line	Function	Number of GPIO pin	Comments
GPIO2	SDA	3	Lines pulled up to +3,3 V with 4,7kΩ resistors
GPIO3	SCL	5	Lines pulled up to +3,3 V with 4,7kΩ resistors

# Installation of expander on RaspberryPi minicomputer



# Installation of expander on RaspberryPi+ minicomputer





BTC Korporacja  
05-120 Legionowo  
ul. Lwowska 5  
tel.: (22) 767-36-20  
faks: (22) 767-36-33  
e-mail:  
[biuro@kamami.pl](mailto:biuro@kamami.pl)  
<https://kamami.pl>

Zastrzegamy prawo do wprowadzania zmian bez uprzedzenia.

Oferowane przez nas płytki drukowane mogą się różnić od prezentowanej w dokumentacji, przy czym zmianom nie ulegają jej właściwości użytkowe.

BTC Korporacja gwarantuje zgodność produktu ze specyfikacją.

BTC Korporacja nie ponosi odpowiedzialności za jakiekolwiek szkody powstałe bezpośrednio lub pośrednio w wyniku użycia lub nieprawidłowego działania produktu.

BTC Korporacja zastrzega sobie prawo do modyfikacji niniejszej dokumentacji bez uprzedzenia.